

N	Part Description	No. off	From	Until	N	Part Description	No. off	From	Until
4010	Fuel feed pump	1			4560	Screw M6 X 25	2		
4020	Fuel feed pump joint	1			4570	Washer spring M6	2		
4040	Fuel feed pipe	1			4580	Split pin	2		
4050	Fuel filter	1			4610	Bolt 2BA X 1/2"	4		
4060	Fuel filter bracket	1	1.72	349.77	4620	Nut 2BA	2		
4061	Filter Bracket	1	350.77		4630	Spring washer 2BA	4		
4070	Fuel filter element	1			4640	Injector nozzle	1		
4090	Fuel pipe (main Feed)	1			4650	Fuel F.P. cover	1		
4100	Fuel pipe (pump drain)	1			4660	1/8" fuel nut	1		
4110	Non-return valve	2			4670	1/8" Fuel olive	1		
4120	Constant bleed valve	1			4680	Hand primer	1		
4130	Banjo bolt—filter vent	1			4690	Exchange F.P. Pump	opt		
4140	Filter blank plug	1			4700	Exchange fuel injector	opt		
4150	Diaphragm kit F.F.P.	1			4760	Throttle return spring	opt	1979	
4160	Banjo union	1			4770	Morse terminal	opt	1979	
4170	Fuel injection pump	1	1.72	1499.9	4780	3/8" SS plain washer	opt	1979	
4171	Fuel injection pump	1	1500.9		4790	1/4" SS split pin	opt	1979	
4180	Pump mounting stud	3							
4200	Nut 1/2" UNF	11			5010	Starter motor assembly	1	1.72	169.74
4210	Pump joint	1			5011	Starter motor	1	170.74	214.74
4220	Fuel HP del pipe no. 1 cyl	1			5012	Starter motor	1	215.74	
4230	Fuel HP del pipe no. 2 cyl	1			5030	Nut 3/8" UNC	2		
4240	Fuel HP del pipe no. 3 cyl	1			5040	Spring washer 3/8"	5		
4250	Fuel HP del pipe no. 4 cyl	1			5050	Starter pinion assembly	1		
4260	Pipe clip (pr)	2			5060	Starter pinion	1		
4270	Fuel injector	4			5070	Locknut starter earth	1		
4280	Injector stud	8			5080	Alternator 15 ACR	1	1.72	60.73
4300	Injector seat washer	4			5080	Alternator 15 ACR	1	170.74	52.75
4310	Injector leak off pipe assembly	3			5081	Alternator 5AC 24V	1	61.73	169.74
4320	Leak off fm filter assembly	1	7.72	349.77	5081	Alternator 17 ACR	1	53.75	1526.9
4321	Leak off pipe assembly	1	350.77		5083	Alternator and tachowire	1	1527.9	
4330	Constant bleed pipe assembly	1			5090	Alternator spacer short	1		
4340	Banjo bolt	4			5100	Alternator spacer long	1		
4350	No. 1 cyl. banjo bolt	1			5110	Alternator stud	1		
4360	Banjo washer (injector)	12			5120	Nut 1/2" Nyloc	2		
4370	Banjo washer pump	1			5130	Alternator adj strap	1	1.72	287.77
4380	Banjo washer (filter)	2			5131	Strap alternator	1	288.77	
4390	Banjo washer (filter head)	1			5150	Main harness	1		
4400	Fuel pump morse terminal	2			5160	Wiring harness engine	1		
4410	Fuel pump stop cable	1			5170	Panel standard s.	1	1.72	1463.9
4411	Fuel pump stop cable	1	1979		5171	Panel std (temp w/l)	1	1464.9	1559.9
4420	Cable clamp	1			5172	Panel std VDO	1	1560.9	
4430	Throttle arm	1			5180	Voltmeter 24 V VDO	1	61.73	169.74
4431	Throttle lever	opt	1979		5190	Oil indicator	1		
4440	Stop cable bracket	1			5200	Alternator indicator	1		
4450	Stop cable return spring	1			5210	Keyswitch and key	1		
4460	Pipe nut 1/2 X 1/2 UNC	6			5220	Mounts	opt		
4470	Olive 1/2	6			5221	Mounts	opt		
4490	Nut	2			5230	Bolts 1/2" BSF X 1 1/2	opt		
4520	Bolt	2			5240	Spring washer 1/2"	opt		
4540	Washer shakeproof	8							

